

YY-201 立体声多功能太阳能应急电源说明书
YY-201 Stereo Solar Portable Power Station User Manual




商品描述:

Product Description:



按键功能说明:

Button Function Description:



- (1) 按第一下开机，电量显示，语言提示等待连接，打开手机蓝牙找到[Bluetooth]设备名，点击连接，连接成功后，手机即可播放音乐。

Press the Main Switch button for the first time, the battery power is displayed, and the language prompts to wait for the connection. Turn on the Bluetooth of the smart phone to find the [Bluetooth] device name, and click the connection. After the connection is successful, the smart phone can play the music.

按第二下关机，电量指示会延时一会才关闭。

Press the Main Switch button for the second time, and the battery indicator will turn off after a delay.

- (2) 开机后：按第一下大灯按钮强光
按第二下大灯按钮弱光
按第三下大灯按钮关闭大灯

After power on: press the Lamp Switch button for the first time, the light is strong.

press the Lamp Switch button for the second time, the light is weak.

press the Lamp Switch button for the third time to turn off the Lamp.

- (3) 开机后：按第一下手电筒按钮强光
按第二下手电筒按钮弱光
按第三下手电筒按钮弱光+爆闪灯
按第四下手电筒按钮爆闪灯
按第五下手电筒按钮关闭爆闪灯

After power on: press the Flashlight Warning button for the first time, the light is strong.

press the Flashlight Warning button for the second time, the light is weak.

press the Flashlight Warning button for the third time the light is weak and burst flashing.

press the Flashlight Warning button for the fourth time light is burst flashing.

press the Flashlight Warning button for the fifth time to turn off the burst flashing light.

- (4) 开机后：按第一下音量减小，长按音量连续减小

After power on: press the Volume - button for the first time to reduce the volume, and press it and hold for a long time and the volume will decrease continuously.

- (5) 开机后：按第一下音量增大，长按音量连续增大，增至最大时，喇叭会发出嘟嘟响。

After power on: press Volume + button for the first time to increase the volume, and press it and hold for a long time and the volume will increase continuously. When it increases to the maximum, the horn will beep.

USB 音乐播放：开机状态下插上 U 盘，即会自动播放音乐。蓝牙与 USB 音乐同时存在时以 USB 音乐优先。

USB Music Play: Plug in the USB flash drive when the device is turned on, and the music will be played automatically.

When Bluetooth and USB music exist at the same time, USB music takes priority.

手机充电口：插上手机后，在未按开机键的状态下会自动给手机充电，同时也有电量指示。

Smart Phone Charging Port: After plugging in the smart phone, it will automatically charge the smart phone without pressing the Main Switch button, and there is also a power indicator.

外接充电口：可接 5V 充电器，5V 太阳能板等 5V 电源。需注意正负极

Charging Port: can be connected to 5V chargers, 5V solar panels and other 5V power sources.

Pay attention to the positive and negative poles.

外接 5V5W 灯：禁止超载使用。

External 5V5W Light: Prohibit overloading.

技术参数 Technical Parameter:

外壳材质 Shell Material	ABS	电池 Battery Capacity	3200mAh
DC 输入 DC Input	5V2A	主灯 Lamp	8W
太阳能板 Solar Panel	6V 1.5W	光源规格 Light specification	40LED
蓝牙音箱 Bluetooth Speaker	立体声 10W Stereo 10W	流明 Lumen	1040LM
USB 充电 USB Charging	5V2A 输出 5V2A Output	手电筒 Flashlight	1W
DC-3.5 输出 DC-3.5 Output	2*5WLED	产品尺寸 Product Size	180mm*65mm*112mm
机器重量 Product Weight	0.7kg	包装尺寸 Packing Size	200mm*70*mm*133mm
整箱 Whole Carton	20 台/箱 20 PCS/Carton	外箱尺寸 Carton Size	42cm*36.5cm*28.5cm

使用注意事项:

Precautions for use:

1.使用前请将电池反过来安装，因出货前是倒装的。

Please install the battery in reverse before use, because it is installed upside down before shipment.

2.不要将光线直接射入人的眼睛。

Don't shoot light directly into people's eyes.

3.不要将本电源放在高温，潮湿，雨淋易燃性气体，腐蚀性物质的地方。

Do not place the device in a place with high temperature, humidity, rain, flammable gas and corrosive substances.

4.更换电池时，正负极不能装反，不要使用其他型号电池或其它电池代替原有电池。

When replacing the battery, the positive and negative poles cannot be reversed, and do not use other types of batteries or other batteries to replace the original battery.

5.不要自行拆开或企图自修复本电源,未经授权的开盖或修复,不在保修之内。

Do not disassemble or attempt to repair the device by yourself. Unauthorized disassembly or repair is not covered under warranty.